Electromagnetic Testing Lecture Guide

Text Corrections

The following text corrections apply to the first and second printings of the *Electromagnetic Testing Lecture Guide.* The next printing of this publication will incorporate the corrections into the published text. Corrections are underlined.

p. 76:

4. Fill factor = d^2 / D^2 (inside coil)
where d = coil winding outside diameter and D = test object internal diameter
or $\underline{d}^2 / \underline{D}^2$ (encircling coil)
where D = coil winding inner diameter and d = test object outside diameter

___

Cat. No. 1653B
Text correction 03/13